



HEIDENHAIN

DR. JOHANNES HEIDENHAIN GmbH
D-8225 Traunreut · Tel. (08669) 31-0

Kundendienst

Service Manual TNC 113

Changes/Developments

We are constantly working on technical improvements of our products. For this reason, details described in this manual may differ slightly from your control. In such cases, please order a revised service manual from us.

Duplication

This manual is provided subject to the condition that no part of it shall be duplicated in any form without our express consent.

Issue KD 2/93

Contents

Section Page

How to Use This Service Manual	0	2
1. Safety Precautions	1	1
2. Error Diagnosis	2	1
2.1 Test Program	2.1	1...2
2.2 Error Messages of the Integrated Monitoring System and The Causes	2.2	1...2
3. Instructions for Exchanging Components	3	1...2
3.1 Dismantling the TNC 113	3.1	1...2
3.2 Installing the TNC 113	3.2	1
4. Appendix	4	
4.1 Internal DIL Switches	4.1	1...2
4.2 Machine Parameters	4.2	1
4.3 Interface and Connector Layouts	4.3	1
4.4 Wiring Diagrams	4.4	1...2
4.5 Power Supply	4.5	1
4.6 NC Software	4.6	1
4.7 Overview: Versions, Components, Software	4.7	1



How to Use This Service Manual

The **ServiceManual TNC 113** can be used to **diagnose** and **locate** errors on machine tools controlled by a TNC. It comprises **exchange instructions** that are important if a defect has occurred.

In order to correctly judge problems in an NC-controlled machine tool, fundamental knowledge of the machine, its drives and their interaction with the control and the measuring systems are required.

Incorrect behavior of the machine tool can also result from improper use of the control, NC-programming errors and incorrect machine parameters.

For information on

- . **Operation**
- . **Operating Modes**
- . **Positioning**
- . **Electrical Connection and Commissioning**

please see the **Operating Manual TNC 113**

In case of problems regarding the **interface** of the control to the machine tool, the **machine parameters** or the setting of the internal **DIL-switches**, please contact your **machine tool manufacturer**.

Support will, however, also be provided by the service department of **HEIDENHAIN Traunreut** or of the **HEIDENHAIN agencies**.

Telephone numbers, addresses and FAX-numbers can be found on the back side of this service manual.



2. Error Diagnosis

The TNC 113 features a comprehensive **integrated error monitoring system** for the **detection of technical defects**

- . in the control electronics
- . at the encoders
- . during positioning

and to **avoid input and operator errors.**

After switching on the control, a test program is run automatically.

Certain parts of the control electronics, the encoders and the positioning are **permanently monitored** during operation.

2.1 Test Program

In the test program (duration approx. 5 seconds) the following functions are tested:

- . Displays of actl. value and input value: (display board)
- . LEDs (display board)
- . EPROM (display board)
- . RAM (display board)
- . TIMER (analog board)


Test: Actl. value display, input value display, LEDs

 after approx. 2 sec.
duration approx. 3 sec.

Visual Check:

- . all segments of the actual value display and the input value display must be lit with the same light intensity.
- . All decimal points of the input value display must be lit.
- . The decimal points of the actual value display are lit from the second decade on.
- . All LEDs are lit.

actl. value display input value display






If an error is detected during the visual check, the complete control must be sent to us for repair!

Test EPROM, RAM, TIMER


If an error is detected, the lower row of LEDs blinks.

Moreover, an error code is displayed by the LEDs of the reference point keys.



The following error codes are possible:

ROM- error (display board)
 RAM- error (display board)
 TIMER-error (analog board)



If the same error code is generated repeatedly, even if the control is switched off and on several times, the complete control must be sent to us for repair. Please indicate the error code.




after approx. 5 sec.

After the test program has been run without any error occurring, the TNC 113 switches to its "normal" operating state i.e.:

the preset values are displayed in the actual value displays, "0" is displayed in the input value display.

the LEDs of the keys  and  are lit.




2.2 Error Messages of the Integrated Monitoring Systems and their Causes

In case of **failure**, the TNC 113 automatically generates **error messages** while opening the contact "Servo Drive Release" (to stop the machine).

2.2.1 Defective Measuring System

Failure of a measuring system is indicated by blinking of the actual value display of the corresponding axis.




Switch off power, eliminate error*, switch on power again.


*Possible Error Causes:

- . Glass scale / steel scale contaminated or damaged
- . Scanning unit contaminated or defective
- . Cable damaged (short circuit / interruption)
- . Encoder input of control defective (analog board)


Encoder Check



3. Instructions for Exchanging Components



TNC 113 Id.No. 216 130 01
 TNC 113 Id.No. 216 130 03
 TNC 113 B Id.No. 233 205 01





TNC 113 Id.No. 216 130 10
 TNC 113 Id.No. 216 130 13
 TNC 113 Id.No. 216 130 15
 TNC 113 Id.No. 216 130 23 *


- ① Id. label
- ② program label (NC-software number)
- ③ dummy plug PG 16 (4 DIL switches)
- ④ line voltage selector
- ⑤ power switch
- ⑥ socket for power connection
- ⑦ grounding terminal
- ⑧ female flange socket, 22-pin (nom. value output, trigger signal outputs)
- ⑨ female flange socket, 9-pin (encoder inputs)
- ⑩ fixing screws

3.1 Power Supply

Old housing (see versions overview, section 4.7, page 1)



New housing (see versions overview, section 4.7, page 1)



3.2 Dismantling the TNC

Model

Id.No.

Serial No.


Progr. No.

e.g.

Model	TNC 113	
Id.No.	216 130 10	
S.No.	4 281 662 A	M8

Progr. 216 916 03

Only with **TNC 113** Id.No. 216 130 01
TNC 113 Id.No. 216 130 03
TNC 113 B Id.No. 233 205 01



Only with **TNC 113** Id.No. 216 130 10
TNC 113 Id.No. 216 130 13
TNC 113 Id.No. 216 130 15
TNC 113 Id.Nr. 216 130 23

MP 1.1




MP 1.2

MP 1.3


MP 2

MP 3

CE + 1	⇒ e.g.	<input type="text" value="P 1.1"/> <input type="text" value="0"/>
Y	⇒ e.g.	<input type="text" value="P 1.2"/> <input type="text" value="0"/>
Z	⇒ e.g.	<input type="text" value="P 1.3"/> <input type="text" value="0"/>
CE + 2	⇒ e.g.	<input type="text" value="P 2"/> <input type="text" value="1"/>
CE + 3	⇒ e.g.	<input type="text" value="P 3"/> <input type="text" value="0"/>
CE		



z.B.



3.3 Installing the TNC 113

Model	TNC 113	1)	?
Id.-No.	216 130 10	2)	
S.-No.	4 281 662 A	M8	

Progr.216 916 03 ³⁾

Model	TNC 113	1)
Id.No.	216 130 10	2)
Serial No.	5 136 722 B	M12
Progr. No.	216 916 01	3)

1) and 2) must be identical

3) The first 6 positions of the Id.No. (e.g. 216 916 ..) must be identical.

The version (e.g. 03) of the exchange unit may be higher than that of the original unit (e.g. 01).

Only for TNC 113, Id.No. 216 130 versions 10, 13, 15, 23

- | | | | |
|----------------------|--------|--------------|--------------------------------|
| CE + 1 | ⇒ e.g. | P 1.1 0 | (MP 1.1: counting direction x) |
|----------------------|--------|--------------|--------------------------------|
- | | | | |
|------------|---|--------------|------------------------------|
| +/- | ⇒ | P 1.1 1 | (0 → positive, 1 → negative) |
|------------|---|--------------|------------------------------|
- | | | | |
|--|---|---|-------------------------------|
|  | ⇒ | 0 | (storage of programmed value) |
|--|---|---|-------------------------------|
- | | | | |
|----------------------|--------|--------------|--|
| CE + 1 | ⇒ e.g. | P 1.1 1 | |
|----------------------|--------|--------------|--|
- | | | | |
|----------|--------|--------------|--------------------------------|
| Y | ⇒ e.g. | P 1.2 0 | (MP 1.2: counting direction Y) |
|----------|--------|--------------|--------------------------------|
- | | | | |
|--|---|------------------|--|
| +/- /  | ⇒ | change / storage | |
|--|---|------------------|--|
- | | | | |
|----------------------|--------|---|--------------------------------|
| CE + 1 | ⇒ e.g. | } | (MP 1.3: counting direction Z) |
|----------------------|--------|---|--------------------------------|
- | | | | |
|----------|---|----------------|--|
| Z | ⇒ | ⇒ as x-/y-axes | |
|----------|---|----------------|--|
- | | | | |
|--|---|--|--|
| +/- /  | ⇒ | | |
|--|---|--|--|
- | | | | |
|----------------------|--------|------------|------------------------------------|
| CE + 2 | ⇒ e.g. | P 2 1 | (MP 2: Y-axis as position display) |
|----------------------|--------|------------|------------------------------------|
- | | | | |
|------------|---|-----------|---|
| +/- | ⇒ | P2 0 | (0 → axis controlled, 1 → position display) |
|------------|---|-----------|---|
- | | | | |
|---|---|---|-------------------------------|
|  | ⇒ | 0 | (storage of programmed value) |
|---|---|---|-------------------------------|
- | | | | |
|----------------------|--------|-----------|--|
| CE + 3 | ⇒ e.g. | P3 0 | (multipoint error compensation X-axis) |
|----------------------|--------|-----------|--|
- | | | | |
|------------|---|-----------|----------------------------------|
| +/- | ⇒ | P3 1 | (0 → no comp., 1 → comp. 50µm/m) |
|------------|---|-----------|----------------------------------|
- | | | | |
|---|---|-------------------------------|--|
|  | ⇒ | (storage of programmed value) | |
|---|---|-------------------------------|--|



4. Appendix

4.1 Internal DIL switches



The internal DIL switches are located on the analog output board. By setting these DIL switches, the machine-tool manufacturer can define the positioning behaviour of the machine tool.



The DIL switches may only be set by the machine tool manufacturer, as incorrect settings may cause severe damage to the machine tool.

TNC 113 Id.No. 216 130 01
 TNC 113 Id.No. 216 130 03
 TNC 113 B Id.No. 233 205 01


TNC 113 Id.No. 216 130 10
 TNC 113 Id.No. 216 130 13
 TNC 113 Id.No. 216 130 15
 TNC 113 Id.No. 216 130 23



Software 212 916 --

DIL switch assignment (see also page 2)

- 1 no function
- 2 } setting the characteristic of the positioning ramp (4 different ramp lengths)
- 3 }
- 4 as 246 040
- 5 as 246 040, but with 180 mV
- 6 as 246 040
- 7 no function
- 8 as 246 040



DIL switch assignment:

- 1 counting direction X
- 2 counting direction Y
- 3 counting direction Z
 - on: positive
 - off: negative
- 4 Y-axis as position display
 - on: axis controlled
 - off: axis as position display

Software 246 040 --

DIL switch assignment (see also page 2)

- 1 no function
- 2 } setting the characteristic of the positioning ramp (4 different ramp lengths)
- 3 }
- 4 selection of analog output
 - on: unipolar
 - off: bipolar
- 5 starting voltage to start a positioning (300mV) for a traverse of 200 µm
 - on: with starting voltage
 - off: without starting voltage
- 6 waiting time before servo drive release
 - on: no waiting time
 - off: waiting time 150 ms
- 7 always set to "off" position
- 8 selection of the grating period
 - on: 40 µm
 - off: 20 µm

Software 246 088 --


DIL switch assignment:

as with software 246 040 --



The characteristics of the positioning ramps are 8 times as steep as those of the software 246 040 --.



4.1 Positioning Ramp Characteristic (Setting via DIL switches)



Notes



4.2 Machine Parameters




Only for TNC 113	Id.No. 216 130 10	with Software 246 040 ..
	Id.No. 216 130 13	246 088 ..
	Id.No. 216 130 15	
	Id.No. 216 130 23	

The machine parameters are stored in non-volatile memory.

Parameters can only be entered/alterd in the operating modes.

To call parameters

press the following keys simultaneously:



To alter parameters

press:



To exit the parameter display

without saving changes

press



and save changes

press



CE + **1** (**X**) ⇒ MP 1.1 counting direction X-axis

CE + **1** (**Y**) ⇒ MP 1.2 counting direction Y-axis

CE + **1** (**Z**) ⇒ MP 1.3 counting direction Z-axis

} 0 → positive
1 → negative

CE + **2** ⇒ MP 2 Y-axis is position display

0 → axis controlled
1 → position display

CE + **3** ⇒ MP 3 multipoint error compensation
X-axis

0 → on
1 → off

Value of multipoint error compensation: 50 µm/m

Counter display x 1.000050 = compensated value



The machine parameters may only be altered by the machine tool manufacturer!




Pin Layout of the Flange Socket for Encoder Connection


	Pin	3	4	1	2	5	6	7	8	9*
		+	-	+	-	+	-	+	-	
	Assignment	lamp U _I		output signal (0° el.) I _{e1}		output signal (90° el.) I _{e1}		ref. signal I _{e0}		shield
	Input signals electr. values	+5V ± 5% approx. 120 mA		for HEIDENHAIN linear and rotary encoders without integrated pulse shaping electronics						

* Internal shield on pin 9
External shield on connector housing


Interface and Connector Layout



4.4 Wiring Diagrams





TNC 113 Id.Nr. 216 130 01
TNC 113 Id.Nr. 216 130 03
TNC 113 B Id.Nr. 223 205 01




TNC 113 Id.Nr. 216 130 10
 TNC 113 Id.Nr. 216 130 13
 TNC 113 Id.Nr. 216 130 15
 TNC 113 Id.Nr. 216 130 23

4.5 Power Supply



4.6 NC Software



Display Board, Id.No. 216 333 01/ 264 372 01


The operating program of the TNC 113 is stored in the EPROM **IC-P1** on the display board.

NC-Software Id.No. **XXX XXX XX**

NC-Software number **XXX XXX**

update index **XX**

e.g.




Id.No. of programmed EPROM **XXX XXX XX**

program number **XXX XXX**

update index **XX**

e.g.



4.7 Overview: Versions, Components, Software

Control Model	TNC 113	TNC 113	TNC 113 B	TNC 113	TNC 113	TNC 113	TNC 113	
Id.No.	216 130 01	216 130 03	233 205 01	216 130 10	216 130 13	216 130 15	216 130 23	
Housing	"old"	"old"	"old"	"new"	"new"	"new"	"new" +4 bore holes M5	
Encoder (grating period)	40μ	20μ	20μ	40μ/20μ	40μ/20μ	40μ/20μ	40μ/20μ	
Power Supply Board 219 096 01								
Power Supply Board 265 306 01								
Analog Board 212 627 01								
Analog Board 260 966 01								
Analog Output Board 215 847 01								
Analog Output Board 261 036 01								
Display Board 216 333 01								
Display Board 264 372 01								
NC-Software 212 916 ..								
NC-Software 246 040 ..								
NC-Software 246 088 ..								



Notizen

Notes

