



- F = Maschinenführung
- R = Referenzmarken-Lage
- L = Maßstablänge
- S = Beginn der Messlänge ML
- G = Klebstoff gemäß Montageanleitung
- 1 = Optische Mitte
- 2 = Überstand Schraubenkopf max. 0.5mm
- 3 = Anschlagfläche Maßstab
- 4 = Montageflächen
- 5 = Bewegungsrichtung des Abtastkopfs für Ausgangssignale gemäß Schnittstellen-Beschreibung
- 6 = Fixpunkt zur Definition des thermischen Fixpunktes
- 7 = Klebeband (nur bei Maßstab geklebt)
- 8 = Montageabstand Abtastkopf zu Maßstab; wird bei Montage mit Abstandsfolie eingestellt

- F = Machine guideway
- R = Reference mark position
- L = Scale length
- S = Beginning of measuring length (ML)
- G = Adhesive as per the mounting instructions
- 1 = Optical center
- 2 = Max. protrusion of screw head 0.5mm
- 3 = Scale stop surface
- 4 = Mounting surfaces
- 5 = Positive direction of scanning head movement for output signals in accordance with interface description
- 6 = Fixed point for defining the thermal fixed point
- 7 = Adhesive tape (only if the scale is adhesively bonded)
- 8 = Mounting clearance of scanning head to scale; adjusted by means of a spacer shim

Original drawing		LIP 2x1		ID number:
Scale	Format	LIP 2x1		Change No. C127187-06
1:2	A2	Anschlussmaße / Mating Dimensions		Phase: Serie
Tolerances as per ISO 8015				General Tolerances ISO 2768:1989-mH ±0.2
The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design. (ISO 16016)				Released
HEIDENHAIN		DR. JOHANNES HEIDENHAIN GmbH		Version
83301 Traunreut, Germany		10.10.2024		Revision
		D1384817-01-A-01		Sheet
		Document number		Page
				1 of 1