




HEIDENHAIN



LIDA 473

LIDA 483

Mounting Instructions

English (en)
06/2025

Table of contents

1	Basic information.....	4
1.1	Validity of the documentation.....	4
1.2	Target groups of the Mounting Instructions.....	4
1.3	Notes on reading the documentation.....	5
1.4	Symbols and fonts used for marking text.....	6
1.5	Notes in this documentation.....	7
1.6	Units and tolerances.....	7
2	Safety.....	8
2.1	Personnel qualification.....	8
2.2	General safety precautions.....	8
3	Items supplied and accessories.....	10
3.1	Items supplied.....	10
3.1.1	Items supplied with the linear scale.....	10
3.1.2	Items supplied with the scanning head.....	11
3.2	Mounting accessories.....	12
3.2.1	Accessories for mounting the linear scale.....	12
3.2.2	Accessories for mounting the scanning head.....	13
3.2.3	Accessories for fixed-point bonding.....	13
3.2.4	Accessories for activating the limit switches.....	14
4	Mounting.....	15
4.1	Requirements and notes.....	15
4.2	Mounting the linear scale.....	16
4.2.1	Choosing the mounting variant.....	16
4.2.2	Variant: Mounting with adhesive film.....	17
4.2.3	Variant: Mounting with fixing clamps.....	21
4.3	Mounting the scanning head.....	27
4.3.1	Choosing the mounting variant.....	27
4.3.2	Variant: Mounting with the holder on the side.....	28

4.3.3	Variant: Mounting with the holder at top.....	30
4.3.4	Variant: Mounting with the holder at bottom.....	32
5	Adjustment and diagnosis.....	34
5.1	Requirements and notes.....	34
5.2	Continuity check.....	34
5.2.1	Materials and tools.....	34
5.2.2	Measuring the electrical resistance.....	34
5.3	Selecting the scanning head.....	35
5.4	Adjustment and diagnosis of LIDA 47.....	36
5.4.1	Connecting the encoder to the PWT.....	36
5.4.2	Adjusting the scanning head.....	40
5.4.3	Checking the function indicator.....	43
5.4.4	Activating the limit switches.....	44
5.5	Adjustment and diagnosis of LIDA 48.....	46
5.5.1	Connecting the encoder to the PWT.....	46
5.5.2	Adjusting the scanning head.....	50
5.5.3	Checking the function indicator.....	52
5.5.4	Activating the limit switches.....	53
6	Final steps.....	55
6.1	Connecting the encoder to the downstream electronics.....	55
7	Removal.....	56
7.1	Safety precautions regarding removal.....	56
7.2	Removing the scanning head.....	56
7.3	Removing the scale.....	56

1 Basic information


This chapter contains information about the product and the Mounting Instructions.

1.1 Validity of the documentation

These Mounting Instructions apply to LIDA 473, LIDA 483.

- Before using the documentation, check whether the documentation and product model match. The designation of the product is printed on the ID label.

ID label



ID label with legend

- 1 Product name
- 2 Measuring length (ML)
- 3 Product ID / Part number (ID)
- 4 Serial number (SN)

1.2 Target groups of the Mounting Instructions

The Mounting Instructions must be read and observed by every person who performs any of the following tasks:

- Design
- Mounting
- Removal

1.3 Notes on reading the documentation

WARNING

Fatal accidents, personal injury or property damage caused by non-compliance with the documentation!

Failure to comply with the documentation may result in fatal accidents, personal injury or property damage.

- ▶ Read the documentation carefully from beginning to end
- ▶ Keep the documentation for future reference

The following table lists the various parts of the documentation in their order of reading priority.

Document type	Description
Addendum	An Addendum supplements or supersedes the corresponding contents of the Operating Instructions and, if applicable, of the Mounting Instructions. If an Addendum is included in the shipment, it has the highest priority for reading. All other documentation content retains its validity.
Operating Instructions	The Operating Instructions contain all of the information and safety instructions for the proper and intended operation of the device. The Operating Instructions (English language version) are included in delivery and can also be downloaded in other languages from www.heidenhain.com/documentation . The Operating Instructions must be read prior to initial operation of the product. The Operating Instructions have the second highest priority for reading.
Mounting Instructions	The Mounting Instructions contain all the information and safety precautions needed for the proper mounting and installation of a product. The Mounting Instructions are not included in delivery and must be downloaded from www.heidenhain.com/documentation . The Mounting Instructions have the third highest priority for reading.

Would you like any changes, or have you found any errors?

We are continuously striving to improve our documentation for you. Please help us by sending your suggestions to the following e-mail address:

userdoc@heidenhain.de

1.4 Symbols and fonts used for marking text

In these instructions the following symbols and fonts are used for marking text:

Format	Meaning
▶ ...	Identifies an action and the result of this action
> ...	Example: <ul style="list-style-type: none"> ▶ Tilt the shipping brace to remove it (c) > The shipping brace has been removed now
■ ...	Identifies an item of a list
■ ...	Example: <ul style="list-style-type: none"> ■ Solid contaminants: class 3 ■ Max. pressure dew point: class 4

1.5 Notes in this documentation

Safety precautions

Precautionary statements warn of hazards in handling the product and provide information on their prevention. Precautionary statements are classified by hazard severity and divided into the following groups:

DANGER

Danger indicates hazards for persons. If you do not follow the avoidance instructions, the hazard **will result in death or severe injury**.

WARNING

Warning indicates hazards for persons. If you do not follow the avoidance instructions, the hazard **could result in death or serious injury**.

CAUTION

Caution indicates hazards for persons. If you do not follow the avoidance instructions, the hazard **could result in minor or moderate injury**.

NOTICE

Notice indicates danger to material or data. If you do not follow the avoidance instructions, the hazard **could result in property damage**.

Informational notes

Informational notes ensure reliable and efficient operation of the product. Informational notes are divided into the following groups:



The information symbol indicates a **tip**.
A tip provides important additional or supplementary information.



The book symbol indicates a **cross reference**.
A cross reference leads to external documentation, for example: further documentation from HEIDENHAIN or another supplier.



The globe symbol represents a **cross reference** to a source on the Internet, e.g. www.heidenhain.de.

1.6 Units and tolerances

Unless otherwise specified, the dimensions stated in these Mounting Instructions are given in millimeters.

Unless otherwise specified, the tolerances stated in these Mounting Instructions conform to ISO 8015 and ISO 2768 standards.

mm



Tolerancing ISO 8015
ISO 2768:1989-mH
≤ 6 mm: ±0.2 mm

2 Safety

This chapter provides important safety information needed for the proper mounting and installation of the product.

2.1 Personnel qualification

Mounting, initial configuration and removal must be conducted by a qualified specialist under compliance with local safety regulations.

2.2 General safety precautions

WARNING

Danger of electric shock due to connection to unsuitable downstream electronics!

If you connect unsuitable downstream electronics to the product, fatal accidents or severe personal injuries can occur.

- ▶ Connect the product only to downstream electronics whose supply voltage comes from PELV systems

WARNING

Live plug connections!

If you disengage plug connections while the equipment is under power, this may result in fatal accidents or severe personal injury.

- ▶ Do not engage or disengage any connecting elements while the product is under power

WARNING

Risk of injury from damaged or worn components!

Safety functions can fail if damaged or worn components are installed unintentionally. Failed safety functions can result in death or serious injury.

- ▶ Inspect the component for damage
- ▶ Do not use any damaged or worn components
- ▶ In case of replacement, repair the thread
- ▶ Use new screws, spring pins and nuts
- ▶ Secure screws and nuts with suitable material-bonding anti-rotation lock

NOTICE

Property damage due to mechanical stress!

- ▶ Do not drop the product or subject it to major vibration
- ▶ Do not expose the product to mechanical stress
- ▶ Do not change the physical structure of the product

NOTICE**Property damage due to electrical stress!**

- ▶ Do not engage or disengage any connecting elements while the product is under power
- ▶ Do not touch the contacts of the plug connections

NOTICE**Electrostatic discharge (ESD)!**

This product contains electrostatically sensitive components that can be destroyed by electrostatic discharge (ESD).




- ▶ It is essential to observe the safety precautions for handling ESD-sensitive components
- ▶ Never touch connector pins without ensuring proper grounding
- ▶ Wear a grounded ESD wristband when handling the connections of the product

3 Items supplied and accessories






This chapter contains information on the items supplied and the available accessories of the product.

3.1 Items supplied

3.1.1 Items supplied with the linear scale

Component	Figure
Linear scale	
Operating Instructions	
Quality Inspection Document	

3.1.2 Items supplied with the scanning head

Component	Figure
Scanning head	
Spacer shim, 0.15 mm (not needed)	
Spacer shim, 0.75 mm	
Operating Instructions	
Manufacturer's Inspection Document	

3.2 Mounting accessories

The following accessories can be ordered separately from HEIDENHAIN.




For more information on the listed products, please refer to the applicable Mounting Instructions and the **Exposed Linear Encoders** brochure.




- ▶ www.heidenhain.com/documentation
- ▶ Enter the document ID **208960**

3.2.1 Accessories for mounting the linear scale



Accessories for mounting with adhesive film

Designation	ID	Figure
Roller	276885-01	


Accessories for mounting with fixing clamps

Designation	ID	Figure
Spacer shim	1176441-xx	
Fixing clamps	1176458-xx	
Fixed-point elements	1176475-xx	

3.2.2 Accessories for mounting the scanning head

Designation	ID	Figure
PWT 101 testing device	1261013-01	
or		
PWM 21 inspection device	1200635-51	




Adjusting and Testing Software (ATS)





The ATS is available for download free of charge.

- ▶ www.heidenhain.com/service/downloads/software/
- ▶ Open the **Categories** selection menu
- ▶ Select the **Inspection and testing devices** category

3.2.3 Accessories for fixed-point bonding

Designation	ID	Figure
Dispensing nozzles and mixing tubes	1176444-01	
Adhesive 3M DP 460 EG	1180444-01	
Double-cartridge gun	1180450-01	

3.2.4 Accessories for activating the limit switches

Designation	ID	Figure
Magnet, north pole	362581-01	
Magnet, south pole	362582-01	

4 Mounting

This chapter describes the mounting requirements, different mounting variants, and all other tasks necessary when mounting.


4.1 Requirements and notes

NOTICE

Property damage due to inappropriate tools!

Using inappropriate tools for mounting or removal of the encoder may cause damage to the encoder.

- ▶ Do not use hammers
- ▶ Do not use pointed or sharp-edged tools





Choose a mounting attitude such that the traverse range is within the measuring length (ML) of the encoder.

(S) = Beginning of measuring length (ML)

Protect the graduation from direct contamination.

In order to ensure correct operation of the encoder, the scale or scale tape must be positioned correctly relative to the scanning head.

Reference mark at top if cable outlet is to the right.



In order to avoid signal interferences, observe the minimum clearance from sources of interference (e.g., power lines).



For more information on sources of interference, refer to the **Interfaces of HEIDENHAIN Encoders** brochure.

- ▶ www.heidenhain.com/documentation
- ▶ Enter the document ID **1078628**





For more information on mounting, refer to the **Mating Dimensions** document.

- ▶ www.heidenhain.com/documentation
- ▶ Enter the product ID
- ▶ Open **Mating Dimensions**

4.2 Mounting the linear scale

4.2.1 Choosing the mounting variant


Mounting variants for the linear scale

Mounting with adhesive film	Mounting with fixing clamps
 <p data-bbox="113 902 212 936">Page 17</p>	 <p data-bbox="799 902 898 936">Page 21</p>

4.2.2 Variant: Mounting with adhesive film


The mounting variant described in this chapter refers to mounting of the linear scale with an adhesive film.

An overview of the mounting variants is provided on Page 16.



Notes on mounting with adhesive film


Note that the mounting surface, as well as the surface of the scale, must be clean and free of paint, dust or grease.



*) Mounting surface of the magnets for activating the limit switches

i You can mount the linear scale by means of stop pins or an aligning rail.

The mounting tolerances refer to the machine guideway **(F)**.




*) Magnets for activating the limit switches


Number of stop pins to be used

Recommended diameter of the stop pins: 3 mm.

For a measuring length of **ML ≤ 2040**, use three stop pins to stabilize the scale sufficiently.



For a measuring length of **ML > 2040**, use five stop pins to stabilize the scale sufficiently.



Materials and tools

For this task, the following materials and tools are needed:

Included in delivery

To be provided separately


- Stop pins
- Roller
- Dispensing nozzle and mixing tubes
- Adhesive 3M DP 460 EG
- Double-cartridge gun

Gluing the linear scale


Attach the scale with adhesive mounting film only at a temperature of > 15 °C.

Pay attention to the expiration date on the package.


- ▶ Insert the stop pins
- ▶ Remove the protective foil from the adhesive film



- ▶ Carefully place the scale onto the stop pins
- ▶ Starting from the center, evenly press the scale onto the mounting surface using the roller
- ▶ Remove the stop pins




- ▶ Do not perform further work on the linear scale until the maximum adhesive force has been reached



i The maximum adhesive force of the mounting film is reached at room temperature after approx. 70 hours.

Bonding the fixed point


Due to potential thermal effects, HEIDENHAIN recommends fixed-point bonding at the center.



i Pay attention to the work instructions in the applicable documentation.

i Do not add more adhesive afterwards.

- ▶ Apply a bead of adhesive with a double cartridge gun and a dispensing nozzle.
- ▶ Allow the adhesive to harden as appropriate for the intended operating temperature



To ensure high fixed-point rigidity, pay attention to the specifications for curing temperature and curing time.


Operating temperature	Curing temperature	Curing time
-10 °C to +30 °C	22 °C	24 hours
-10 °C to +70 °C	80 °C	3 hours

Next step: "Mounting the scanning head", Page 27

4.2.3 Variant: Mounting with fixing clamps


The mounting variant described in this chapter refers to mounting of the linear scale with fixing clamps.

An overview of the mounting variants is provided on Page 16.




Notes on mounting with fixing clamps

Note that the mounting surface, as well as the surface of the scale, must be clean and free of paint, dust or grease.



*) Mounting surface of the magnets for activating the limit switches

The mounting tolerances refer to the machine guideway (F).




*) Magnets for activating the limit switches


Number of stop pins to be used

Recommended diameter of the stop pins: 3 mm.

For a measuring length of **ML ≤ 2040**, use three stop pins to stabilize the scale sufficiently.



For a measuring length of **ML > 2040**, use five stop pins to stabilize the scale sufficiently.



Materials and tools

For this task, the following materials and tools are needed:


Included in delivery

To be provided separately


- Fixing clamps
- Spacer shims
- Stop pins
- Fixed-point elements
- Screws (DIN 7984 – M3x6)
- Washers (ISO 7092–3)
- Torque wrench (hexagon socket for 2.5 mm)
- Dispensing nozzle and mixing tubes
- Adhesive 3M DP 460 EG
- Double-cartridge gun

Mounting the fixing clamps

- ▶ Insert the stop pins
- ▶ Remove the protective film of the scale
- ▶ Carefully place the scale onto the stop pins




- ▶ Press all fixing clamps lightly in the direction of the scale and fasten them with screws and washers. Tighten the screws only lightly



Perform the following steps only with those fixing clamps that are nearest to, but across from, a stop pin:

- i** For a measuring length of $ML \leq 2040$
= 2 fixing clamps
For a measuring length of $ML > 2040$
= 4 fixing clamps

ML ≤ 2040
= 2x




ML > 2040
= 4x



- ▶ Place the spacer shim between the fixing clamp and scale
- ▶ Align the fixing clamp at a right angle to the scale
- ▶ Tighten the screw using the prescribed torque





Do not remove the spacer shims.




Mounting the fixed-point element

Pay attention to the mounting dimensions. Deviations from the mounting dimensions lead to imprecise measurement results during operation.


- ▶ Align the fixed-point element in parallel
- ▶ Lightly press the upper fixed-point element against the scale and fasten it with screws using the prescribed torque



- ▶ Remove the stop pin




- ▶ Align the fixed-point element in parallel
- ▶ Lightly press the lower fixed-point element against the scale and fasten it with screws using the prescribed torque



Tightening the fixing clamps


- i**
- The figure shows an example. The number and position of the fixing clamps and stop pins depends on the length of the linear scale.
 - Always tighten the fixing clamps in pairs.

- ▶ Place the spacer shims between each pair of fixing clamps and the scale
- ▶ Tighten the screws using the prescribed torque
- ▶ Remove the spacer shims and use them for the next pair of fixing clamps
- ▶ Tighten the screws in the sequence shown



*) Do not remove the spacer shims from the first tightened fixing clamps until all fixing clamps have been tightened.

- ▶ Remove the stop pin
- ▶ Finally, tighten the fixing clamp opposite the first fixing clamp that was tightened
- ▶ Tighten the screws on the other side of the fixed-point element according to the same pattern




Bonding the fixed-point elements

i Pay attention to the work instructions in the applicable documentation.

i Do not add more adhesive afterwards.

- ▶ Apply a bead of adhesive with a double cartridge gun and a dispensing nozzle.
- ▶ Allow the adhesive to harden as appropriate for the intended operating temperature



To ensure high fixed-point rigidity, pay attention to the specifications for curing temperature and curing time.




Operating temperature	Curing temperature	Curing time
-10 °C to +30 °C	22 °C	24 hours
-10 °C to +70 °C	80 °C	3 hours

Next step: "Mounting the scanning head", Page 27

4.3 Mounting the scanning head

4.3.1 Choosing the mounting variant


Mounting variants for the scanning head

Holder on the side	Holder at the top
 <p data-bbox="113 813 213 846">Page 28</p>	 <p data-bbox="799 813 900 846">Page 30</p>
<p data-bbox="331 857 580 891">Holder at the bottom</p>  <p data-bbox="113 1160 213 1193">Page 32</p>	

4.3.2 Variant: Mounting with the holder on the side

The mounting variant described in this chapter refers to mounting of the scanning head with the holder on the side.

An overview of the mounting variants is provided on Page 27.



Notes on mounting the scanning head with the holder on the side



i The tightening torques of the mounting screws are only valid for mounting on steel.

NOTICE

Property damage due to unsuitable cleaning agents!

- ▶ Use only isopropyl alcohol to clean the encoder
 - ▶ Clean the encoder with a lint-free cloth
- ▶ If necessary, clean the graduation and the scanning head with a lint-free cloth and isopropyl alcohol

Pay attention to the mounting dimensions. Deviations from the mounting dimensions lead to imprecise measurement results during operation.



Materials and tools

For this task, the following materials and tools are needed:

Included in delivery


- Spacer shim

To be provided separately


- Two screws (ISO 4762–M3×(a+5))
- Two washers (ISO 7092–3)
- Torque wrench (hexagon socket for 2.5 mm)

Mounting the scanning head

- ▶ If necessary, remove the protective cap from the scanning head
- ▶ If necessary, remove the protective film from the scale




- ▶ Prepare the spacer shim



- ▶ If necessary, clean the spacer shim with a lint-free cloth and isopropyl alcohol

i When mounting the linear scale with fixing clamps:
Do not insert the spacer shim near the fixing clamps.

- ▶ Use the spacer shim to set the mounting clearance
- ▶ Lightly tighten the screws on the scanning head
- ▶ Remove the spacer shim




Next step: "Adjustment and diagnosis", Page 34

4.3.3 Variant: Mounting with the holder at top

The mounting variant described in this chapter refers to mounting of the scanning head with the holder at top.

An overview of the mounting variants is provided on Page 27.



Notes on mounting the scanning head with the holder at top



i The tightening torques of the mounting screws are only valid for mounting on steel.

NOTICE

Property damage due to unsuitable cleaning agents!

- ▶ Use only isopropyl alcohol to clean the encoder
 - ▶ Clean the encoder with a lint-free cloth
- ▶ If necessary, clean the graduation and the scanning head with a lint-free cloth and isopropyl alcohol

Pay attention to the mounting dimensions. Deviations from the mounting dimensions lead to imprecise measurement results during operation.



Materials and tools

For this task, the following materials and tools are needed:

Included in delivery


- Spacer shim

To be provided separately


- Two screws (ISO 4762–M3×(a+7))
- Two washers (ISO 7092–3)
- Torque wrench (hexagon socket for 2.5 mm)

Mounting the scanning head

- ▶ If necessary, remove the protective cap from the scanning head
- ▶ If necessary, remove the protective film from the scale




- ▶ Prepare the spacer shim



- ▶ If necessary, clean the spacer shim with a lint-free cloth and isopropyl alcohol

i When mounting the linear scale with fixing clamps:
Do not insert the spacer shim near the fixing clamps.

- ▶ Use the spacer shim to set the mounting clearance
- ▶ Lightly tighten the screws on the scanning head
- ▶ Remove the spacer shim




Next step: "Adjustment and diagnosis", Page 34

4.3.4 Variant: Mounting with the holder at bottom

The mounting variant described in this chapter refers to mounting of the scanning head with the holder at bottom.

An overview of the mounting variants is provided on Page 27.



Notes on mounting the scanning head with the holder at bottom



i The tightening torques of the mounting screws are only valid for mounting on steel.

NOTICE

Property damage due to unsuitable cleaning agents!

- ▶ Use only isopropyl alcohol to clean the encoder
 - ▶ Clean the encoder with a lint-free cloth
- ▶ If necessary, clean the graduation and the scanning head with a lint-free cloth and isopropyl alcohol

Pay attention to the mounting dimensions. Deviations from the mounting dimensions lead to imprecise measurement results during operation.



Materials and tools

For this task, the following materials and tools are needed:

Included in delivery


- Spacer shim

To be provided separately


- Two screws (ISO 4762–M3×(a+7))
- Two washers (ISO 7092–3)
- Torque wrench (hexagon socket for 2.5 mm)

Mounting the scanning head

- ▶ If necessary, remove the protective cap from the scanning head
- ▶ If necessary, remove the protective film from the scale




- ▶ Prepare the spacer shim



- ▶ If necessary, clean the spacer shim with a lint-free cloth and isopropyl alcohol

i When mounting the linear scale with fixing clamps:
Do not insert the spacer shim near the fixing clamps.

- ▶ Use the spacer shim to set the mounting clearance
- ▶ Lightly tighten the screws on the scanning head
- ▶ Remove the spacer shim



Next step: "Adjustment and diagnosis", Page 34

5 Adjustment and diagnosis

This chapter describes the continuity test, as well as the adjustment and diagnosis with a testing device (e.g., PWT 101).

5.1 Requirements and notes

A testing device (e.g., PWT 101) is required for adjustment and diagnosis. As an alternative, an inspection device (e.g., PWM 21) can be used.



For more information, refer to the **PWT 100/PWT 101** Operating Instructions.

- ▶ www.heidenhain.com/documentation
- ▶ Enter the document ID **1162581**



For more information, see the **Exposed Linear Encoders** brochure.

- ▶ www.heidenhain.com/documentation
- ▶ Enter the document ID **208960**

5.2 Continuity check

5.2.1 Materials and tools

For this mounting step, the following materials and tools are needed:

Included in delivery

To be provided separately


- Resistance measuring device

5.2.2 Measuring the electrical resistance

- ▶ Check the electrical resistance between the connector housing and the machine



The electrical resistance between the connector housing and the machine must be $< 1 \Omega$.



5.3 Selecting the scanning head

Scanning head variants	
LIDA 47	LIDA 48
Scanning head with TTL interface Page 36	Scanning head with 1 V _{PP} interface Page 46

5.4 Adjustment and diagnosis of LIDA 47

5.4.1 Connecting the encoder to the PWT

Connecting the encoder

NOTICE

Property damage due to electrical stress!

- ▶ Do not engage or disengage any connecting elements while the product is under power

- ▶ Connect the encoder to the PWT 101
- ▶ Connect the PWT 101 to the power supply


Selecting the connection

Connection options

Connecting the encoder automatically	Connecting the encoder manually
Recommended option with automatic determination of the measuring parameters. Page 37	Alternative option if the encoder cannot be connected automatically. Page 38

Connecting the encoder automatically

- ▶ Tap **Automatic Diagnosis** in the main menu
- > The **Automatic Diagnosis** is performed.
- > The **Level display** screen is opened.


**Main menu**

If you cannot connect the encoder automatically, proceed as described in the **Connecting the encoder manually** chapter.

Next step: "Adjusting the scanning head", Page 40


Connecting the encoder manually

- ▶ Tap **Manual diagnostics** in the main menu
- ▶ The **Supply voltage of encoder** screen is opened.




Main menu

- ▶ Select the supply voltage
- ▶ Activate the **Adjust supply voltage** checkbox, if required
- ▶ Swipe right to left
- ▶ The **Encoder interface** screen is opened.




Supply voltage of encoder screen

- ▶ Select the encoder interface
- ▶ Swipe right to left
- ▶ The **Manual diagnostics** screen is opened.



Encoder interface screen

- ▶ Check your selection
- ▶ Tap **Connect**
- > The connection to the encoder is established.
- > The **Level display** screen is opened.




Manual Diagnosis screen

Next step: "Adjusting the scanning head", Page 40

5.4.2 Adjusting the scanning head


- ▶ Swipe the **Level display** screen to the right
- ▶ The **PWT display** screen is opened.



Level display screen

In the **PWT display** screen, you can evaluate the incremental and reference mark signals based on the bar diagrams. HSP is automatically deactivated in the **PWT display** screen.


- *) If **HSP OFF** blinks, then HSP is deactivated.



PWT display screen




For the mounting variant with the holder on the side, the blind hole in the scanning head can be used for the adjustment.




Setting the incremental signal

The black bar represents the current signal amplitude of the incremental signals. The farther the black bar moves to the right, the larger the signal amplitude is.

- ▶ Rotate the scanning head to set the maximum possible signal amplitude




- ▶ Lightly tighten the screws



Set the reference mark signal

- ▶ Traverse the reference mark (R) with the scanning head




- ▶ Tap lightly to rotate the scanning head a minimum distance to set the optimal reference mark signals.


*) Green = good

***) Optimal

- ▶ Ensure that the incremental signals do not decrease




- ▶ Tighten the screws with the specified torque




5.4.3 Checking the function indicator

The function indicator permits fast and easy signal-quality checks.




If the LED blinks green after adjustment, proceed as follows:

- ▶ Clean the measuring standard and the scanning window of the scanning head
- ▶ Check the mounting tolerance
- ▶ Repeat adjustment



LED blinks



LED shines green



For more information, see the **Exposed Linear Encoders** brochure.

- ▶ www.heidenhain.com/documentation
- ▶ Enter the document ID **208960**



5.4.4 Activating the limit switches

Mounting the magnets for the limit switches


Using the magnets for the limit switches, you can detect the end positions.

Ensure that the magnets are oriented correctly.

T = carrier side




- ▶ Wipe to switch to the **Switching signals** screen



Switching signals screen

- ▶ Traverse the scanning head to the desired position
- ▶ Move the magnet until L1 or L2 shows a signal change
- ▶ Mark the position of the magnet
- ▶ Clean the mounting surface, if required
- ▶ Remove the protective film of the scale
- ▶ Attach the magnet





For more information, see the **Exposed Linear Encoders** brochure.

- ▶ www.heidenhain.com/documentation
- ▶ Enter the document ID **208960**



For more information, refer to the **Interfaces of HEIDENHAIN Encoders** brochure.

- ▶ www.heidenhain.com/documentation
- ▶ Enter the document ID **1078628**

Next step: "Final steps", Page 55

5.5 Adjustment and diagnosis of LIDA 48

5.5.1 Connecting the encoder to the PWT

Connecting the encoder

NOTICE

Property damage due to electrical stress!

- ▶ Do not engage or disengage any connecting elements while the product is under power

- ▶ Connect the encoder to the PWT 101
- ▶ Connect the PWT 101 to the power supply


Selecting the connection

Connection options

Connecting the encoder automatically	Connecting the encoder manually
Recommended option with automatic determination of the measuring parameters.	Alternative option if the encoder cannot be connected automatically.
Page 47	Page 48

Connecting the encoder automatically

- ▶ Tap **Automatic Diagnosis** in the main menu
- > The **Automatic Diagnosis** is performed.
- > The **PWT display** screen is opened.


**Main menu**

If you cannot connect the encoder automatically, proceed as described in the **Connecting the encoder manually** chapter.

Next step: "Adjusting the scanning head", Page 50


Connecting the encoder manually

- ▶ Tap **Manual diagnostics** in the main menu
- ▶ The **Supply voltage of encoder** screen is opened.




Main menu

- ▶ Select the supply voltage
- ▶ Activate the **Adjust supply voltage** checkbox, if required
- ▶ Swipe right to left
- ▶ The **Encoder interface** screen is opened.




Supply voltage of encoder screen

- ▶ Select the encoder interface
- ▶ Swipe right to left
- ▶ The **Manual diagnostics** screen is opened.



Encoder interface screen

- ▶ Check your selection
- ▶ Tap **Connect**
- > The connection to the encoder is established.
- > The **PWT display** screen is opened.




Manual Diagnosis screen

Next step: "Adjusting the scanning head", Page 50


5.5.2 Adjusting the scanning head

In the **PWT display** screen, you can evaluate the incremental and reference mark signals based on the bar diagrams.



PWT display screen


i For the mounting variant with the holder on the side, the blind hole in the scanning head can be used for the adjustment.




Setting the output signals

The black bar represents the current output signals.

- ▶ Rotate the scanning head to set the output signals to $1 V_{PP}$




- ▶ Lightly tighten the screws



Set the reference mark signal

- ▶ Traverse the reference mark (**R**) with the scanning head




- ▶ Tap lightly to rotate the scanning head a minimum distance to set the optimal reference mark signals.


***)** Green = good

****)** Optimal

- ▶ Ensure that the incremental signals do not decrease




- ▶ Tighten the screws with the specified torque




5.5.3 Checking the function indicator

The function indicator permits fast and easy signal-quality checks.




If the LED blinks green after adjustment, proceed as follows:

- ▶ Clean the measuring standard and the scanning window of the scanning head
- ▶ Check the mounting tolerance
- ▶ Repeat adjustment



LED blinks



LED shines green



For more information, see the **Exposed Linear Encoders** brochure.

- ▶ www.heidenhain.com/documentation
- ▶ Enter the document ID **208960**


5.5.4 Activating the limit switches

Mounting the magnets for the limit switches


Using the magnets for the limit switches, you can detect the end positions.

Ensure that the magnets are oriented correctly.

T = carrier side




- ▶ Wipe to switch to the **Switching signals** screen



Switching signals screen

- ▶ Traverse the scanning head to the desired position
- ▶ Move the magnet until L1 or L2 shows a signal change
- ▶ Mark the position of the magnet
- ▶ Clean the mounting surface, if required
- ▶ Remove the protective film of the scale
- ▶ Attach the magnet





For more information, see the **Exposed Linear Encoders** brochure.

- ▶ www.heidenhain.com/documentation
- ▶ Enter the document ID **208960**



For more information, refer to the **Interfaces of HEIDENHAIN Encoders** brochure.

- ▶ www.heidenhain.com/documentation
- ▶ Enter the document ID **1078628**

Next step: "Final steps", Page 55

6 Final steps

6.1 Connecting the encoder to the downstream electronics

WARNING

Danger of electric shock due to plug connections under voltage!

Connecting and disconnecting live cables and plug connections in the equipment can result in death or serious injury.

- Only connect and disconnect cables and plug connections when no current is flowing through them
- Disconnect the downstream electronics from power before connecting the product
- For cables without connectors, pay attention to the pin layout

- ▶ Connect the encoder to the downstream electronics

NOTICE

Property damage resulting from incorrect routing of the connecting cable!

Connecting cables may become damaged as a result of incorrect routing.

- ▶ Observe the maximum permissible bend radii
- ▶ Do not cross connecting cables in drag chains
- ▶ Route connecting cables professionally



For more information on the cable characteristics and cable routing, refer to the **Cables and Connectors** brochure.

- ▶ www.heidenhain.com/documentation
- ▶ Enter the document ID **1206103**



For more information on the pin layouts, refer to the **Cables and Connectors** brochure.

- ▶ www.heidenhain.com/documentation
- ▶ Enter the document ID **1206103**



For more information on sources of interference, refer to the **Interfaces of HEIDENHAIN Encoders** brochure.

- ▶ www.heidenhain.com/documentation
- ▶ Enter the document ID **1078628**

7 Removal

This chapter describes the disassembly of the product.

7.1 Safety precautions regarding removal

WARNING

Live plug connections!

If you disengage plug connections while the equipment is under power, this may result in fatal accidents or severe personal injury.

- ▶ Do not engage or disengage any connecting elements while the product is under power

WARNING

Moving machine parts!

Risk of injury due to moving machine parts depending on the installation location and the application

- ▶ Observe all of the machine manufacturer's notes on working on the machine (e.g., always disconnect the machine from the power supply)

CAUTION

Fragile carrier material of the graduation!

Risk of injury from splinters and sharp edges of the carrier material

- ▶ Wear protective gloves and safety goggles
- ▶ Do not bend or deform the measuring standard excessively

7.2 Removing the scanning head

- ▶ Remove the scanning head in the reversed sequence of mounting.
Further information: "Mounting the scanning head", Page 27

7.3 Removing the scale



Further information can be found in the **Disassembly Instructions**.

- ▶ www.heidenhain.com/documentation
- ▶ Enter the document ID **1185755**

HEIDENHAIN

DR. JOHANNES HEIDENHAIN GmbH

Dr.-Johannes-Heidenhain-Straße 5

83301 Traunreut, Germany

☎ +49 8669 31-0

☎ +49 8669 32-5061

info@heidenhain.de

Technical support ☎ +49 8669 32-1000

Measuring systems ☎ +49 8669 31-3104

service.ms-support@heidenhain.de

NC support ☎ +49 8669 31-3101

service.nc-support@heidenhain.de

NC programming ☎ +49 8669 31-3103

service.nc-pgm@heidenhain.de

PLC programming ☎ +49 8669 31-3102

service.plc@heidenhain.de

APP programming ☎ +49 8669 31-3106

service.app@heidenhain.de

www.heidenhain.com