



HEIDENHAIN

Austauschanleitung
Replacing Instructions

EXE 804
EXE 922

10/2008

Bitte folgende Schritte beachten:

1. Netzkabel entfernen.
2. Messgerätekabel markieren (Y - X).



EXE 804

3. Messgerätekabel von der EXE 804 entfernen.
4. Ausgangskabel (Harting und 9-pol.) entfernen.
5. Bei Bedarf eines zweiten TTL-Ausganges bzw. eines Sinusausganges muss an die EXE 922 ein Anbaugehäuse (Harting, ID 284477-01) bzw. Flanschdose (Sinusausgang, ID 237280-01) angebaut werden.



6. Messgerätekabel Y an X3; X an X1 der EXE 922 wieder anstecken.



EXE 922

7. Ausgangskabel wieder anstecken.

Please observe the steps below:

- 1. Remove the power cord.*
- 2. Label the encoder cables (Y - X).*



EXE 804

- 3. Disconnect the encoder cables from EXE 804.*
- 4. Remove the output cables (Harting and 9-pin).*
- 5. If a second TTL output or a sinusoidal output is required, an external mounting housing (Harting, ID 284477-01) or a flange socket (sinusoidal output, ID 237280-01) must be mounted to EXE 922.*



- 6. Reconnect the encoder cables to EXE 922: Y to X3; X to X1.*



EXE 922

- 7. Reconnect the output cable.*