


## Montageanleitung Mounting Instructions

### Abtastkopf Scanning Head WMK 2005

### AMO GmbH

A-4963 St. Peter am Hart  
Nöfing 4




Phone: +43 7722 658 56-0  
e-mail: [office@amo.at](mailto:office@amo.at)  
[www.amo-gmbh.com](http://www.amo-gmbh.com)



2011879

MA\_WMK\_2005\_1216\_00

## Warnhinweise Warnings



**Achtung:** Die Montage und Inbetriebnahme ist von einer qualifizierten Fachkraft unter Beachtung der örtlichen Sicherheitsvorschriften vorzunehmen.

- Die Steckerverbindung darf nur spannungsfrei verbunden oder gelöst werden.
- Montageflächen müssen sauber und gratfrei sein.
- Der direkte Kontakt von Flüssigkeiten mit Messgerät und Steckverbinder ist zu vermeiden.
- Der Antrieb darf während der Montage nicht in Betrieb gesetzt werden.

**Note:** Mounting and commissioning is to be conducted by a qualified specialist under compliance with local safety regulations.

- Do not engage or disengage any connections while under power.
- Mounting surfaces must be clean and free of burrs.
- Avoid direct contact of fluids with the encoder and connector.
- The drive must not be put into operation during mounting.

