

Anschlussbelegung WB 64B26
Belegung

BELEA1 WB
 ANELA1 64B26 (26 Pin Female D-Sub 3-row without housing)

Pin #	Signal Name
1	Trigger 3B
2	Trigger 3A
3	Trigger 4B
4	Trigger 4A
5	Trigger 5A
6	Trigger 5B
7	NC
8	Term Out
9	GND
10	GND
11	E1 TX-
12	E1 TX+
13	Reset Out Term
14	+24V
15	+24V
16	Trigger 2B
17	Trigger 2A
18	GND
19	E1 RD+
20	E1 RD-
21	NC
22	NC
23	Connect Out
24	NC
25	Trigger 1A
26	Trigger 1B
Shield	Case Ground

Note the protection mark for ISO 16016!

Edited on: **Erstausgabe / first edition**



Release-No.		Created	Responsible	Released	Version	Rev.	Sheet	Page
FR2657	Name	Spunaugle		Rivas	D752474 - 00 - B - 01			1/
	Date	27.08.2012		14.10.2013	Document no.			1