



- ① ② ③ = Montage-Möglichkeiten
- F = Maschinenführung
- \* = max. Änderung bei Betrieb (IKS: Inkrementalspur, RI: Referenzmarkenspur)
- Ⓢ = Beginn der Messlänge ML
- Ⓡ = Referenzmarken-Lage
- Ⓛ = Maßbandlänge
- ⓐ = Auslesemagnet für Limit-Schalter
- Ⓜ = Montagefläche für Abtastkopf ③
- ① = Funktionsanzeige
- ② = Abtastspalt
- ③ = Anschlagfläche Maßband
- ④ = Bewegungsrichtung der Abtasteinheit für Ausgangssignale gemäß Schnittstellen-Beschreibung

- Mounting option
- Machine guideway
- max. change during operation (IKS: incremental-track, RI: reference-pulse-track)
- Beginning of measuring length ML
- Reference mark position
- Scale tape length
- Selector magnet for limit switch
- Mounting surface for scanning head ③
- Status display
- Scanning gap
- Stop surface scale tape
- Direction of scanning unit motion for output signals in accordance with interface description

Original drawing			IDnumber:	
Scale	Format	LIDA 4x9	Change No.	C083151-06
Dimensions in mm	1:1	A2	Phase:	Serie
Anschlussmaße			Tolerierung nach DIN ISO 8015	
			Tolerances as per DIN ISO 8015	
			Allgemeintoleranzen ISO 2768-mH ±0.2mm; +0.2mm; -0.2mm	
			General tolerances ISO 2768-mH ±0.2mm; +0.2mm; -0.2mm	
The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design. ( ISO 16016 )			Version   Revision   Sheet	
<b>HEIDENHAIN</b> DR. JOHANNES HEIDENHAIN GmbH 83301 Traunreut, Germany			D 1145430 - 02 - A - 01	
			1 of 1	