



M = machine guideway / Maschinenführung
 ML = measuring length / Messlänge
 OL = overall length / Gesamtlänge
 ⊙ = beginning of the measuring length / Beginn der Messlänge
 ←→ = 0 ... ML
 →+ = direction of motion of the scanning unit for ascending position values
 Bewegungsrichtung des Abtastkopfes für steigende Positionswerte

K = customer mounting dimensions / kundenseitige Anschlussmaße

optional / Optionen
 P = M5 air inlet / M5 Luftanschluss
 S1, S2 = switch signals / Schaltsignale
 RI = selectable reference mark / wählbare Referenzmarke
 A = connecting cable / Anschlusskabel
 * = actuator magnet / Schaltmagnet
 ** = sensor position / Sensorposition

Original drawing		Scale		Format		MSA770		ID number: -	
Dimensions in mm		1:1		A2		MSA770		Change No. C157360-16	
						Anschlussmaße / Mating Dimensions		Phase: Serie	
								Tolerances as per ISO 8015	
								General Tolerances ISO 2768:1989-mH ≤ 6:±0.2	
The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Offenders will be held liable for the payment of damages. All rights reserved in the event of a patent, utility model or design. (ISO 16016)									
RSF Elektronik		Released		Version		Revision		Sheet	
www.rsf.at		23.11.2023		D 670864-01-C-01		1 of 1		Page	
				Document number					