



- ⊗ I ⊗ II ⊗ III = Montage-Möglichkeiten / mounting option
- F = Maschinenführung / machine guideway
- ⊗ S ⊗ R ⊗ L ⊗ 1 ⊗ 2 ⊗ 3 ⊗ 4 = Schnittstellen-Beschreibung / interface description
- ⊗ S = Beginn der Messlänge ML / beginning of measuring length ML
- ⊗ R = Referenzmarken-Lage / Reference mark position
- ⊗ L = Maßbandlänge / Scale tape length
- ⊗ 1 = Funktionsanzeige / Status display
- ⊗ 2 = Abtastspalt / Scanning gap
- ⊗ 3 = Anschlagfläche Maßband / Stop surface scale tape
- ⊗ 4 = Bewegungsrichtung der Abtasteinheit für Ausgangssignale gemäß Schnittstellen-Beschreibung / Direction of scanning unit motion for output signals in accordance with interface description

Referenzmarke:
 k = beliebige Position der RI-Marke vom Beginn der Messlänge
 j = zusätzliche RI-Marken im Abstand von n x 100mm

Reference-marks:
 k = any position of reference-mark from the beginning of the measuring length
 j = additional reference-marks separated by n x 100mm

Original drawing		Lida 279 / Lida 289		ID number:
Scale	Format	Lida 279 / Lida 289		Change No. C020319-53
Dimensions in mm	1:1 A3	Anschlussmaße / Mating Dimensions		Phase: Nicht-Serie
				Tolerierung nach DIN ISO 8015 Tolerances as per DIN ISO 8015
				Allgemeintol. ISO 2768-mH ≤ 6mm: ±0.2 General tol. ISO 2768-mH ≤ 6mm: ±0.2

The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design. (ISO 16016)